MOSI - 00097 - A005

PART NO.

INSTRUCTIONS-HEADER MTG.

GO'LE, PAPER

6

+.002 000 Dare 8 / 16/ 85

CKD

ON CENTRICITY TIR 083

HACTIONAL OLE DIA ECIMAL

Please note the following Option Switch Settings for the SAC-I game reflect the state of the game as of November 12, 1984. The option switches are located at 61 and H1 of the SAC-I board, at the top-far end of the board as it sits in the SAC-I Game Cabinet facing from the front.

PRIERSE 28/11/8

FURO-HAT TRICK™
Part No. 020-8012-01-0A
Option Switch Settings

19

Right Coin Mech x 6		OŁŁ -	OFF	-					
Right Coin Mech x 5		OFF.	NO					16	
Right Coin Mach x 4		NO	OFF	- 10					
Right Coin Mech x 1		NO	NO	-1					
Left Coin Mech x 2		140	140	110				-	
Laft Coin Mech x 1				330		4		3	
5 Coins Adds 3 Bonus Coins	*			NO					
5 Coins Adds 2 Bonus Coins					OFF.	OFF	OFF		
5 Colns Adds 1 Bonus Coin					OFF	OFF	NO		
4 Coins Adds 2 Bonus Coins					OFF	NO	OFF		
4 Coins Adds 1 Bonus Coin					OFF	NO	NO		
3 Coins Adds 1 Bonus Coin					NO	OFF	OEE		
aion sured I stok string &					NO	OFF	NO		
2 Coins Adds 1 Bonus Coin					NO	NO	OFF.		
No Bonus Coins	*				NO	NO	NO		19.
2 COINS/1 Credit								OFF	OFF
I COIN/2 Credits								OFF	NO
1 COIN/1 Credit	*			-				NO	OFF
FREE PLAY			-					NO	NO
								110	110
		ठ	Z	9	5	F	2	Z	T
							- 37		
			IH						
	1000								
Attract Sounds	_	NO	XX	XX	VV	State of the last			
No Attract sounds	•	OFF	XX	XX	XX				
1 Player/Credit		330	XX	XX	XX				
1 or 2 Players/Credit			XX		XX	NO		- 1-2	
Geme Time - 1:15	*		XX	XX	XX	OFF	100		100
Geme Time - 1:30				XX	XX		NO	NO	NO
Ceme Time - 1:45			XX	XX	XX		NO	NO	OFF
Geme Time - 2:00			XX	XX	XX		NO	OFF	NO
Geme Time - 2:15	¥		XX	XX	XX		NO	OFF	OFF
Game Time - 2:30			XX	XX	XX		OFF	NO	NO
Geme Time - 2:45			XX	XX	XX		OFF	NO	OFF
Gome Time - 3:00			XX	XX	XX		OFF	OFF	NO
OO.E - amiT arref)			XX	XX	XX		OFF	OFF	OFF
		1 . 1	- /	-	12				
		8	Z	9	3	F	2	2	T
		1							